

Washing Machine Usage & Maintenance tips




Selection of right location

- Avoid direct sun light, Humid place & heat generating area or exposed to rain
- Set the washer on a dry, levelled floor in a well ventilated area.
- Allow 5cm. Space from all the side of washer.
- Level the washer with help of front two adjusting legs to eliminate vibrations.

Selection of right electric connection.

- An exclusive 3 pin 5A wall socket with fuse having 1 ph., 220-240 volts, 50 Hz.,
- Phase on right hand side proper earthing.




Proper fitment of inlet & outlet connection

- Water supply pressure to be with 0.3 - 10 kg/cm².
- Maximum 2-meter extension of water inlet & outlet (drain) hose allowed.
- Change the outlet drainpipe position according to customer requirement.


Preparation before washing

- Sort the cloth.
- Remove pins, coins, keys etc.
- Turn the cloth inside out.
- Put the delicate & small cloth inside the netted basket.
- Select required amount of water as per cloth load.
- Put required amount of detergent.



Wash & Soak selection procedure

- Select soak as per requirement..
- Select cycle setting as per type of fabric & load.
- Select wash timing as per recommended in user manual.(in case of Sammie auto.)



Rinsing procedure


- Perform spin shower rinsing, over flow rinsing or fix amount of rinsing after completing wash to remove total soap from the clothes.

Complete spin procedure

- Incise of Sammie auto transfer the cloth in spin basket fix the spin cap.
- Select the spin cycle setting according to type of fabric.

Ending the process

- Drain the water completely from the drainpipe.
- Then hang the drainage hose.
- Switches off the main power supply and unplug the power cord



Maintenance

- Clean wash tub
- Clean Overflow outlet
- Clean lint filter



Tips for Improving Wash Quality

Given below are few tips that will help you get better results from your washing machine, as well as keep the clothes & washing machine in good condition for a long time.

- Pre-Rinse the clothes before main wash in plain water, as 60% of spoilage can be dissolved. Hence the detergent will be more effective on removing the balance soilage.
- Do not overload the washer.
- Select appropriate water level as per the load so that clothes can freely move around in the detergent water resulting in a good wash.
- Sort your clothes before wash
- Wash whites separately from colors.

Tips for Improving Wash Quality

- Wash less soiled cloths separately from heavily soiled.
- Separate lint givers from lint takers.
- Make sure that all pockets are empty of coins, pins etc.
- Turn garments made of lint taker fabric inside out before washing.
- Do not allow wet clothes to remain in the washer for long period.
- Clean the lint filter regularly
- Wipe your washer clean after every wash.
- Keep washer's lid open for some time after the wash to avoid smell & fungus.